

BEDNET[®] INTERIOR CARGO RESTRAINT WITH MESH

BN-0304

INSTRUCTIONS:

1. Connect carabiner through either of the two grommets* on each upper corner of the Bednet[®].
2. Connect carabiner to both strands of seatbelt where the shoulder belt connects to the wall.
3. Drape Bednet[®] over all cargo in rear seat.
4. Thread cam straps through either of the two grommets* on each lower corner of the Bednet[®].
5. Wrap tag end of cam strap around leg or brace of rear seat base.
6. Then thread strap through cam buckle and tighten.

**For smaller loads, use the grommets located closer to the center of the Bednet[®]. The outer-most grommets are to be used for larger loads.*



For technical information or other questions regarding our products, call toll free 1-866-423-3638 or visit us online at www.thebednet.com.